72" 1828mm

Suptac 5532 - Blue
Standard - Gold

48" 1220mm



10/00005 - ADV 22 JAN 2010

A MEMBER OF THE GUILD OF MASTER CRAFTSMEN

All designs and artwork are copyright of Acres Signs & Graphics / 01335 347202

ACRES SIGNS & GRAPHICS

Fisher German
2 Rutherford Court, Staffordshire Technology Park, Stafford, ST18 0AR
Tel: 01785 220044 Fax: 01785 220944

Heath House Access

SCALE:	DATE:
1:2500	January 2010

MAP FILE REFERENCE:
ST10/HH/P1.003

Pear Technology Services Ltd 24 First Ave, Havant, Hants PO9 2QN
Based on Ordinance Survey 1:2500 Land-Line data with the permission of the Controller of HMSO © Crown Copyright

N

NG2461
0.42

NG6463
0.02

NG6560
0.13

NG6460
0.03

Lodge

NG6556
0.44

NG7052
0.28

HOLLINGTON ROAD

Lodge

NG4842
7.74

NG1348
0.07

NG4145
0.69

NG6744
0.35

NG2045
0.20

NG3337
0.24

NG3836
0.40

NG6932
0.08

The Stables


NG3434
0.39

NG6431
0.19

NG5327
0.78


Heath
House

ADV 22 JAN 2010


NG6932
0.08
The Stables
NG6431
0.19
NG5327
0.78
NG2226
0.49
Heath
House
NG2824
0.64
NG712
0.03
NG4522
0.29
NG5219
0.94
NG2911
0.18
NG3514
0.47
Lodge
NG2210
0.04
NG1904
0.13
HOUSE LANE
10/00005/ADV
22 JAN 2010
FISHER GERMAN
CHARTERED SURVEYORS
2 Rutherford Court, Staffordshire Technology Park, Stafford, ST18 0AR
Tel: 01785 220044 Fax: 01785 220944
Heath House Access 2
SCALE:
1:2500
DATE:
January 2010
MAP FILE REFERENCE:
ST10/HH/P1.005
Pear Technology Services Ltd, 24 First Ave, Havant, Hants, PO9 2QN
Based on Ordnance Survey 1:2500 Land-Line data with the permission of the Controller of HMSO. © Crown Copyright.
N

powerlite
Lighting Solutions Ltd
Unit H8/H4 Gildersome Spur
Wakefield Road
Morley
LS27 7JZ
Tel: 0118 2450708
Fax: 0118 2422678
info@powerlite-lighting.com
www.powerlite-lighting.com

HYDRA 3 & 4 RANGE
COMPACT FLUORESCENT SIGN LIGHT AND AREA FLOODLIGHT



Safety Information & Installation Instructions

Please read instructions before commencing installation and retain for future reference.

⚠ Safety Information

- To ensure safe installation and use this product should be used only in accordance with the instructions and should not be modified.
- If you have any doubts at all as to the manner of installation or use of this product consult a competent electrician. Installation should be carried out to the current edition of the IEE Wiring Regulations/BS 7671 or the relevant National Wiring Regulations if outside the UK.
- To avoid risk of electric shock disconnect electrical supply before installation.
- This product must be earthed to prevent metal parts becoming live in the event of insulation failure.
- Lamp Replacement: Always disconnect the electrical supply before removing the diffuser or replacing a lamp, see 'Replacing Lamp' overleaf.


Installation Instructions


IMPORTANT NOTE: For models with photo-cell see 'Operation with Photo-cell' overleaf BEFORE installing.

The signlight may be fixed directly to the mounting surface or mounted using a sign arm, available separately as an accessory. **Ensure that the means of mounting is adequate to support the weight of the signlight, particularly when using a sign arm, for weight of each model see 'Specification' overleaf. To avoid damage to plastic parts ensure that any decorative/preservation treatments are thoroughly dry before attaching the signlight. Do not use grease, etc. on the bolts or screws.**

1. To attach the signlight directly to the mounting surface fix the bracket using corrosion resistant screws and wall plugs. Attach the signlight to the bracket with the M8 nuts, bolts and plastic washers supplied. The nuts locate in the slots in the back of the signlight (See drawings).

2. Connect the live supply conductor to the brown lead from the signlight, the supply neutral to the blue lead, and the earth conductor to the green and yellow lead. Ensure the electrical connections are protected against water ingress.





3. To assemble a sign arm to the signlight, fit the soft silicone washer into the threaded hole in the signlight bracket, followed by the hard washer (See drawing).

4. Thread the lead from the signlight down the sign arm, screw the arm into the signlight bracket and secure screwing the locking nut provided up against the bracket.
It is important to screw the arm tightly into the bracket before tightening the lock nut so as to compress the silicone washer - this will prevent water running into the arm.

PSL20 & PSL400 Sign Arms

5. These sign arms may be fitted direct to the mounting surface using corrosion resistant screws and wall plugs or mounted on a standard conduit box. If using a conduit box outside, a conduit box gasket must be fitted to prevent the ingress of water. The sign light angle can be adjusted on the end plate/conduit box cover by loosening the lock nut at the wall end.

cont'd